

## Push Button/Selector Switch/Pilot Lamp

- M22 → Selector Switch/Accessories
- A22 → Push Button /Pilot Lamp



Surge protection  
SPC

## Easy Control Relay

- Easy500 → Stand alone base unit
- Easy700 → Expandable base unit
- Easy800 → Expandable networkbase unit



## Load Center

- LC1 → 160A Busbar
- LC2 → 250A Busbar
- LM → Main Lug

## Magnetic Contactor

- DILM → 7-300A
  - DC Coil
  - AC Coil



## Breaker (MCB/MCCB)

- LZM → 3P/20A-1600A/25,36,50,70KA
- BZM → 3P/16A-100A/15,25KA
- NZM → 3P/20A-1600A/25,36,50KA
- PLS → 1-3P/1A-63A/6KA
- PLSM → 1-3P/1A-63A/10KA



### Air Circuit Breaker

- IZM → 3,4 P/ 50,60 KA ที่ 415V 50Hz
- Fixed Type
- Drawout Type

### Soft Start

- DS → For 3P motor 1.5-200 kW



### Transfer Switch Controller (ATS-C) NZM-XATS

### Safety Switch

- DG → General duty Non-Fusible
- DH → Heavy duty Non-Fusible



### UPS

- 93E/E Series DX/9310/EX/9PX/9PXSP
- 15-400KVA